

Installation Manual

Multitherm Bandage



1

Seal the opening around the service penetration, according to the sealing method installation instructions. Openings up to 20 mm can easily be sealed with Multimastic SP firestop mastic, over a depth of 10 mm.

4

Remove the protective film at the back and wrap the Multitherm Bandage around the service penetration. Make sure that the closing side is at the bottom of the service penetration and that the Bandage has a minimum overlap of 10 mm. Press everything down firmly.

2

Make sure the service penetration is free from dust, dirt and grease.

5

Fill in the conformity statement and paste it next to the fireproof seal.

3

Measure the circumference of the service penetration and cut the Multitherm Bandage to size with a knife, as per the installation overview in the box. Remember to keep an extra length of at least 10 mm to create an overlap



For use and for more information about an application, refer to the Mulcol documentation, local and international approvals. See the **Mulcol Fire Protection app** for the correct application in combination with fire resistance, or use our selector at www.mulcol.com for professional use only.

MULCOL
INTERNATIONAL